

Madison Heights A/C controls:

Easiest way to explain how to control the a/c in the bedroom is that only the “off” and “max” buttons do anything.

Your main (in the lounge room) unit must be on, and temperature and fan speed is selected on this panel.

In the bedroom, “max” opens the vent to allow the cool air from the main unit in, “off” closes the vent to stop air from the main unit coming into your bedroom.

The rest of the buttons on this bedroom panel do nothing.

As the thermostat is located on the panel in the lounge area, the system will adjust according to the temperature there, not in the bedroom, i.e once the temperature in the lounge get to the set temperature, the system may stop cooling regardless of the temperature in the bedroom.